

## QL FAST DRY

# TIPS AND RECOMMENDATIONS

- Due to the fast drying nature of Damar QL Fast Dry we have outlined some recommendations and best practices to use with this product.  
*This is a high specification fast drying product which requires care when handling.*
- Store 1000L Pallecons and 200L Drums out of direct sunlight, heat and frosts.
- Filter product when filling tanks where possible and minimise contact with air.
- Ensure tanks are air tight and take particular note of lid seals.
- Ensure paint lines on the trucks are air tight and either heat reflecting white or silver in colour and are fully UV light proof.
- Flush any filling hoses / pipes after use to avoid internal skinning.
- We recommend filling the tanks at the end of shifts to minimise the air in the tank.
- Once tank is full, spray a small amount of ammonia float across the top of the paint to create a “seal” from the air.  
*Ammonia float is available on our Online Ordering System (Item Key ALK0043)*
- Flush filters on a regular basis.
- Smaller high pressure filters on B Type machines may need more regular cleaning.
- Don’t “vent” Pallecon bags by loosening the top filler bung.
- Higher pressures and larger tips are recommended I.e 1700-2000psi and 25 – 06 tip or similar.